

Step 4. Install Shaft, Shaft brace bar and extension poles

The step is very simple and obvious for every body. You do not need too much wordy explanation. Just see pictures in Fig 6



Fig. 6

There you go! You made it!

Make sure you have tightened all bolts and nuts. Check the tire and brake. You may need to step down several times in order the brake activated. The hydraulic fluid has been added before ship to you. During the shipping the fluid may lose. You need to check the hydraulic fluid level in reservoir You can add some if needed. The volume of fluid should be 5/6 full in reservoir. The reservoir is under your seat in side, right side of the bucket. The right side is the fluid you should use.

Congrats! Now you can hook it up to your horse and enjoy the driving! Smile!
Any Questions? Email to animalsport@att.net

